


型號 DUC252 250MM CORDLESS CHAIN SAW



型號 DUC252 250MM CORDLESS CHAIN SAW

分解圖號	零件編號	品名	交換	數量	N/O	選擇1	選擇2	註記
001	451972-6	FRONT HANDLE		1				
002	266053-1	TAPPING SCREW 4X35		1				
003	265995-6	TAPPING SCREW 4X18		2				
004	643941-3	BRUSH HOLDER CAP		2				
005	194928-3	CARBON BRUSH CB-442		1				
006	644514-5	BRUSH HOLDER		1				
007	644513-7	BRUSH HOLDER		1				
008	815R26-5	DUC252 NAME PLATE		1				
009	620275-1	CONTROLLER		1				
010	187882-8	HOUSING SET		1				
C10	263005-3	RUBBER PIN 6		4				
D10		INC. 53						
011	266173-1	TAPPING SCREW 5X30		1				
012	142574-6	FRONT HAND GUARD COMPLETE		1				
C10	803G42-3	CAUTION LABEL		1				
013	231298-0	COMPRESSION SPRING 6		1				
014	451973-4	HAND GUARD SUPPORT		1				
015	416178-3	LOCK-OFF BUTTON		1				
016	233173-6	COMPRESSION SPRING 4		1				
017	650730-9	SWITCH TG72BD-6		1				
018	450212-9	SWITCH LEVER		1				
019	644808-8	TERMINAL		2				
020	256184-4	PIN 4		1				
021	638571-3	YOKE UNIT		1				
022	451970-0	BAFFLE PLATE		1				
023	266292-3	TAPPING SCREW 4X65		2				
024	210062-2	BALL BEARING 607ZZ		1				
025	519268-2	ARMATURE ASS'Y 36V		1				
D10		INC. 24,26						
026	211092-6	BALL BEARING 629DDW		1				
027	227252-0	SPUR GEAR 16		1				
028	252186-8	HEX. NUT M6		1				
029	256123-4	PIN 5		1				
030	158047-9	LINK PLATE COMPLETE		1				
031	233175-2	COMPRESSION SPRING 9		1				
032	265995-6	TAPPING SCREW 4X18		1				
033	267195-4	FLAT WASHER 4		1				
034	168321-7	BRAKE BAND		1				
035	142573-8	BEARING HOUSING COMPLETE		1				
C10	263002-9	RUBBER PIN 4		1				
C20	414377-1	NOZZLE		1				
036	213039-6	O RING 6		1				
037	422058-3	CONNECTOR		1				
038	210028-2	BALL BEARING 606ZZ		1				
039	961006-2	RETAINING RING S-10		1				
040	221427-3	WORM GEAR		1				
041	227251-2	SPUR GEAR 73		1				
042	326417-2	SPINDLE		1				

