


# 型號 DHP446 CORDLESS HAMMER DRIVER DRILL



# 型號 DHP446 CORDLESS HAMMER DRIVER DRILL

分解圖號	零件編號	品名	交換	數量	N/O	選擇1	選擇2	註記
001	815S38-4	DHP446 NAME PLATE		1				
002	187149-4	HOUSING SET		1				
C10	263005-3	RUBBER PIN 6		2				
D10		INC. 19						
003	266429-2	TAPPING SCREW 3X16		9				
004	126289-3	SPEED CHANGE LEVER ASSEMBLY		1				
C10	233438-6	COMPRESSION SPRING 4		2				
005	419250-0	F/R CHANGE LEVER		1				
006	650731-7	SWITCH C3HZ-1A-TLMS		1				
007	620012-3	LED CIRCUIT		1	*			
007-1	620388-8	LED CIRCUIT	O	1				
008	643866-1	TERMINAL		1				
009	251468-5	- FLAT HEAD SCREW M6X22		1				
010	763175-3	KEYLESS DRILL CHUCK 13		1				
011	126460-9	GEAR ASSEMBLY		1				
012	638425-4	YOKE UNIT		1				
013	619287-9	ARMATURE		1				
014	638494-5	BRUSH HOLDER COMPLETE		1				
015	194427-5	CARBON BRUSH CB-440		1				
016	263032-0	RUBBER PIN 4		2				
017	452205-2	REAR COVER		1				
018	266429-2	TAPPING SCREW 3X16		2				
019	187149-4	HOUSING SET		1				
C10	263005-3	RUBBER PIN 6		2				
D10		INC. 2						
020	232182-2	LEAF SPRING		1				
021	689170-4	HEAT SINK		1				
022	911013-5	PAN HEAD SCREW M3X10		1				
023	424476-1	CUSHION		1				
A01	251314-2	+ SCREW M4X12		1				
A02	346317-0	HOOK		1				
A03	784637-8	+/- BIT 2-45		1				
A04C	141856-3	PLASTIC CARRYING CASE COMPLETE		1				
C10	162302-3	LATCH		2				
C20	324207-7	SHAFT		1				
C30	451749-9	HANDLE		1				
A05C	450128-8	BATTERY COVER		1				
A06C	***DC18RC	DC18RC FAST CHARGER		1	*			
A06-1C	***DC18RC	DC18RC FAST CHARGER	<	1				
A07C	196836-4	BATTERY BL1430 SET		2	*			
A07-1C	196836-4	BATTERY BL1430 SET	O	2	*			
A07-2C	196973-4	BATTERY BL1430 SET	<	2				
A08C	803Y97-6	DHP446RFE PLASTIC CASE LABEL		2				