


# 型號 DTD155 CORDLESS IMPACT DRIVER



# 型號 DTD155 CORDLESS IMPACT DRIVER

分解圖號	零件編號	品名	交換	數量	N/O	選擇1	選擇2	註記
C10	252126-6	六角鎖定螺母M4-7		2				
D10		INC. 35						
001A	183G71-5	HOUSING SET		1				
001B	183G72-3	HOUSING SET		1				
001C	183G71-5	HOUSING SET		1				
001D	183G72-3	HOUSING SET		1				
001E	183G71-5	HOUSING SET		1				
001F	183G72-3	HOUSING SET		1				
002	853G07-5	DTD155 NAME PLATE		1				
003	266429-2	自攻螺絲 3X16		9				
004	455053-8	切換桿		1				
005	143975-1	開關		1				
006	619415-6	ROTOR		1				
007	629233-4	STATOR		1				
008	620521-2	LED電路		1				
009	643860-3	電池接端座		1				
010	231965-7	擋圈 10		1				
011	267143-3	華士 11		1				
012	233005-7	彈簧 13		1				
013	326803-7	BIT SLEEVE		1				
014	424914-3	BUMPER		1				
016	144132-4	HAMMER CASE COMPLETE		1				
017	261159-0	NYLON WASHER 19		1				
018	216002-8	鋼珠 4.8		2				
019	326629-7	鐵站		1				
020	324894-2	鎚		1				
021	216019-1	鋼珠 3		24				
022	267380-9	平板墊片 20		1				
023	232326-4	COMPRESSION SPRING 21		1				
024	267813-4	墊片 21		1				
025	216019-1	鋼珠 3		2				
026	221437-0	SPUR GEAR 17		2				
027	324897-6	車心		1				
028	268217-3	銷 3.5		2				
029	253052-2	平板華士 12		1				
030	227316-0	內環齒輪 43		1				
032	213479-8	O圈 33		1				
033	141893-7	軸承箱		1				
C10	252126-6	六角鎖定螺母M4-7		2				
D10		INC. 1						
035A	183G71-5	HOUSING SET		1				
035B	183G72-3	HOUSING SET		1				
035C	183G71-5	HOUSING SET		1				
035D	183G72-3	HOUSING SET		1				
035E	183G71-5	HOUSING SET		1				
035F	183G72-3	HOUSING SET		1				
036	144137-4	SWITCH PLATE COMPLETE		1				
039	266490-9	盤頭螺絲 PT 2X6		3				

請訂購一個零件。

列印日期 2017/11/16

# 型號 DTD155 CORDLESS IMPACT DRIVER

分解圖號	零件編號	品名	交換	數量	N/O	選擇1	選擇2	註記
041	620586-4	CONTROLLER		1				
A01	266622-8	螺絲M4X12 F/BTD145RFE		1				
A02A	346317-0	掛勾(大)		1				
A02B	346317-0	掛勾(大)		1				
A02C	346449-3	掛勾(小)		1				
A02D	346449-3	掛勾(小)		1				
A02E	346317-0	掛勾(大)		1				
A02F	346317-0	掛勾(大)		1				
A03C	***DC18RC	充電器C/195582-6		1				
A03D	***DC18RC	充電器C/195582-6		1				
A03E	***DC18RC	充電器C/195582-6		1				
A03F	***DC18RC	充電器C/195582-6		1				
A04C	197259-9	鋰電池 顯示型 BL1820B		2				
A04D	197259-9	鋰電池 顯示型 BL1820B		2				
A04E	197287-4	鋰電池 顯示型 BL1850B		2				
A04F	197287-4	鋰電池 顯示型 BL1850B		2				
A05C	450128-8	電池保護蓋		1				
A05D	450128-8	電池保護蓋		1				
A05E	450128-8	電池保護蓋		1				
A05F	450128-8	電池保護蓋		1				
A06C	141856-3	塑料手提箱		1				
C10	162302-3	推板		2				
C20	324707-7	車心		1				
C30	451749-9	握把		1				
A06D	141856-3	塑料手提箱		1				
C10	162302-3	推板		2				
C20	324207-7	軸		1				
C30	451749-9	握把		1				
A06E	141856-3	塑料手提箱		1				
C10	162302-3	推板		2				
C20	324707-7	車心		1				
C30	451749-9	握把		1				
A06F	141856-3	塑料手提箱		1				
C10	162302-3	推板		2				
C20	324207-7	軸		1				
C30	451749-9	握把		1				
E01	163400-6	手提吊帶 F/6503D,6918D		1				