


Model No.DHG181 CORDLESS HEAT GUN



Model No.DHG181 CORDLESS HEAT GUN

分解圖號	零件編號	品名	交換	數量	New/Old	選擇1	選擇2	註記
001	PR00000420	HOUSING SET		1				
D10		INC. 23						
002	PR00000380	LOCK ON BUTTON		1				
003	PR00000381	SPRING9		1				
004	PR00000382	SUPPORT FRAME		1				
005	PR00000293	TAPPING SCREW ST2.9X10		2				
006	PR00000383	HOOK		1				
007	PR00000384	SNAP RING		1				
008	PR00000385	SPRING6		1				
009	PR00000421	REAR COVER		1				
010	PR00000422	HOOK BUTTON		1				
011	PR00000388	SPRING5		1				
012	PR00000423	DIAL		1				
013	PR00000425	INNER COVER		1				
014	PR00000293	TAPPING SCREW ST2.9X10		3				
015	PR00000390	MOTOR ASSEMBLY		1				
016	PR00000427	HEATER ASSEMBLY		1				
C10	PR00000424	NUT 2.5		2				
C20	PR00000426	SCREW 2.5X10		2				
C30	PR00000428	TENSION SPRING 3		2				
017	PR00000392	FRONT COVER ASSEMBLY		1				
018	PR00000393	SPRING 4		1				
019	PR00000394	TRIGGER ASSEMBLY		1				
020	PR00000429	LEAF SPRING		1				
021	PR00000430	CHAGE LEVER		1				
022	PR00000395	TAPPING SCREW ST2.9X16		8				
023	PR00000420	HOUSING SET		1				
D10		INC. 1						
A01	PR00000031	REDUCTION NOZZLE 20mm		1				
A02	PR00000030	REFLECTOR NOZZLE		1				
A03	PR00000029	WIDE-SLOT NOZZLE		1				
A04	PR00000028	GLASS PROTECTION NOZZLE		1				
A05	PR00000404	PLASTIC CASE		1				

Please order the parts with part number.

Print Date 2022/1/27